



# Vortex Flowmeter

## AVF7000 Series

### Operator Manual



# Index

|   |    |
|---|----|
| 1. Flowmeter Check - - - - -                                | 3  |
| 2. Specification - - - - -                                  | 3  |
| 3. Diameter - - - - -                                       | 4  |
| 4. Installation- - - - -                                    | 5  |
| 5. Wiring Chart - - - - -                                   | 7  |
| 5.1 compact version - - - - -                               | 7  |
| 5.2 separate version - - - - -                              | 8  |
| 6. Panel Display - - - - -                                  | 9  |
| 7. Function - - - - -                                       | 9  |
| 7.1 Button Function- - - - -                                | 9  |
| 7.2 Display Function - - - - -                              | 9  |
| 8. General Parameter Operation Chart- - - - -               | 10 |
| 9. Calibration Parameter Operation Chart- - - - -           | 11 |
| 10. General Parameter Setting- - - - -                      | 13 |
| 10.1 Parameter and Adjustment information setting - - - - - | 13 |
| 10.2 Totalization Zero Clearing- - - - -                    | 16 |
| 10.3 Password Revised- - - - -                              | 16 |
| 11. Calibration Parameter Setting- - - - -                  | 17 |
| 11.1 Temp. Calibrate Operation - - - - -                    | 17 |
| 11.2 Pressure Calibrate Operation - - - - -                 | 18 |
| 11.3 Electric current output calibration - - - - -          | 19 |
| 11.4 Zero Point Calibration Operate - - - - -               | 20 |


## 1. Flowmeter Check

- A. First check the package if it is good or damage, if broken hard you should notify the meter transport department or contact the customer service center of Alia immediately
- B. Open the package and check for meter and all parts attachment if it is good or damage and shortage
- C. Read the operating instruction in detail and comprehends all contents, if any part of that you do not understand full, fax technical service department of Alia
- D. Make sure that the specification of the meter you received is conformed to the operating condition
- E. Power on the meter in house, observe the LCD display if it is on normal
- F. Select proper meter install site, make sure to meet the installing condition
- G. Meter be moved to the field and be mounted on the pipe according to the installing requirements
- H. Wiring the power cable, special to care of the shield braid of the cable connected to the grounding terminal of the converter.
- I. Power on the meter in field, first observe if there is any leakage around the meter (care of the personal safety), then the display if it appears any changes of transient flow rate, if it is not, check it as step above carefully, particular to the wiring, power supply, shield braid grounding, the specification of the meter and meter surrounding, or contact technical service center of local agency.


## 2. Specification

|                       |  |                    |   |
|-----------------------|--|--------------------|---|
| ● Size (mm)           | : 10,15,20,25,32,40,65,80,100,125,150,<br>200,250,300,350,400,450,500 mm                                       | ● Protection       | : IP 65.<br><br>Explosion Proof Exd IIC T6  |
| ● Measuring Range     | : Steam – 1.6 to 540,000 Kg/Hr<br><br>Gas - 3 to4 6,000 m3/Hr<br><br>Liquid - 0.3 to 4950 m3/Hr                | ● Local display    | : 4 Line LCD<br><br>4 digit Flowrate<br><br>8 digit Totalization  |
| ● Material            | : Stainless Steel 304 / 316  | ● Output           | : 4~20 mA (2wire)<br><br>Load : 600 Ω   |
| ● Accuracy            | Liquid : +/- 0.7%<br><br>Gas/Steam : +/- 1.0%  | ● Pulse Output     | : Standard Pulse Output<br><br>Output Range : 3 to 30VDC, 20mA Max.   |
| ● Repeatability       | : +/- 0.2%   | ● Communication    | : RS485   |
| ● Connection          | : Flange / Wafer   | ● Data storage     | : Operation Parameter, Totalization Figures<br>are stored by EEPROM.  |
| ● Flange Type         | : JIS 10K / JIS 20K / JIS 40K<br><br>ANSI 150# / ANSI 300# / ANSI 600#<br><br>DIN PN 10 / PN 16 / PN25 / PN 40 | ● Housing Material | : Aluminum Alloy  |
| ● Wafer Type          | : 40,65,80,100,125,150, 200,250<br><br>without Temperature / Pressure Sensor                                   | ● Cable Entry      | : 2x0.5mm2  |
| ● Temperature         | : -40 ~ +280°C ( Standard Type)<br><br>-4 ~ +420 °C (Explosion proof Type)                                     | ● Power Supply     | : 12~36 VDC   |
| ● Ambient Temperature | : -20 ~+60°C   | ● Key Pad          | : 4 keys from internal for Programming and<br>display contro  |
| ● Pressure            | : 78 Kg/cm2 (Max.)   | ● Option           | Pressure Transmitter Pressure Compensation<br><br>Signal Input 0~30 mV DC<br><br>Temperature sensor Temperature sensor<br><br>Signal Input PT100 ( 3 Wire ) |

**3. Diameter**




| Normal Size |        | Dimensions (mm) |     |     |
|-------------|--------|-----------------|-----|-----|
| mm          | Inch   | L1              | D1  | H1  |
| 40          | 1-1/2" | 70              | 85  | 415 |
| 50          | 2"     | 70              | 99  | 425 |
| 65          | 2-1/2" | 70              | 118 | 440 |
| 80          | 3"     | 70              | 132 | 460 |
| 100         | 4"     | 70              | 156 | 480 |
| 125         | 5"     | 70              | 184 | 500 |
| 150         | 6"     | 70              | 211 | 530 |
| 200         | 8"     | 98              | 248 | 578 |
| 250         | 10"    | 114             | 298 | 628 |




| Normal Size |        | Dimensions (mm) |     |
|-------------|--------|-----------------|-----|
| mm          | Inch   | L2              | H2  |
| 10          | 3/8"   | 200             | 428 |
| 15          | 1/2"   | 200             | 430 |
| 20          | 3/4"   | 200             | 435 |
| 25          | 1"     | 200             | 440 |
| 32          | 1-1/4" | 200             | 452 |
| 40          | 1-1/2" | 200             | 468 |
| 50          | 2"     | 200             | 480 |
| 65          | 2-1/2" | 200             | 502 |
| 80          | 3"     | 225             | 515 |
| 100         | 4"     | 250             | 534 |
| 125         | 5"     | 275             | 564 |
| 150         | 6"     | 300             | 593 |
| 200         | 8"     | 350             | 647 |
| 250         | 10"    | 400             | 700 |
| 300         | 12"    | 450             | 750 |
| 350         | 14"    | 500             | 805 |
| 400         | 16"    | 550             | 861 |
| 450         | 18"    | 600             | 910 |
| 500         | 20"    | 650             | 965 |

**4. Installation**


Vortex Flowmeter Pipe installed location is very important, it concerned to measuring accuracy, please left the multiple space in the upstream and downstream of the straight pipe as you can, if the pipe is confirmed with not enough straight pipe, please install 2/3 of total straight pipe length on the upstream, 1/3 on downstream, but the Flowmeter can't matched factory accuracy. Example





● **Grounding measure**

AVF7000 requested the perfect grounding, to erase the interference, the grounding as follow, only need to put the converter housing connected with grounding. Sensor don't need to connected grounding again..  
 Grounding point, ex.: Stairs, metal fence...etc.




### 5. Wiring Chart


This meter uses two wires to transmit 4-20 mA output signal to other external equipment, power supply 11 ~ 36VDC, the maximum loading resistance for output circuit is 600Ω (including resistance of cable wire)

In general condition, 600V PVC isolating wire or cable be used as connecting wire. The two core shielding wire (RWP2×0.5mm) be used in the place where electricity noise occurred easily, the out layer of shielding wire should be connected to the grounding screw in the house of amplifier fixedly. Uses appropriate cable to conform with the operating temperature if the temperature is too high or low.

#### 5.1 compact version




| 4-20 mA Output | Pulse Output | Sensor Input            |                                |
|----------------|--------------|-------------------------|--------------------------------|
|                |              | Temperature             | Pressure                       |
|                |              |                         |                                |
| ON OFF         | ON OFF       | PT100 Ω<br>RTD (3 Wire) | Pressure Transmitter<br>4 Wire |



| 4-20 mA Output               | Pulse Output                 | Sensor Input                    |  |
|------------------------------|------------------------------|---------------------------------|--|
|                              |                              | Temperature                     | Pressure                               |
|                              |                              |                                 |  |
| <p>ON OFF</p> <p>1 2 3 4</p> | <p>ON OFF</p> <p>1 2 3 4</p> | <p>PT100 Ω<br/>RTD (3 Wire)</p> | <p>Pressure Transmitter<br/>4 Wire</p> |



## 6. Panel Display



## 7. Function

### 7.1 Button Function

| Key Name    | Button | Measure state Function                  | Parameter Setting State Function                                   |
|-------------|--------|---|--|
| Setting     | SET    | Go to the parameter setting mode        | Save the parameter setting so far, and go to next parameter.       |
| Move        | >      | Select the contents selected            | Move   |
| Up          | ^      | Change the contents selection           | Revised the present display  |
| Calibration | CAL    | Go to the calibration parameter setting | Save the calibration setting at present, and go to next parameter. |

### 7.2 Display Function

|      |           |
|------|-----------|
| RATE | 10.5 m3/h |
| TOT. | 20.0 m3   |



|      |           |
|------|-----------|
| OUT  | 12.5mA    |
| DEN  | ----kg/m3 |
| E.T. | 23.1°C    |
| IN   | 88hz      |

Display without Temp./ Pressure compensation

If choose the application of "1. Gas" or "2. Liquid ", only 2 lines will display, That is flowrate and totalizer.

Row 1 : output content. If choose current output, it shows the output current value; If choose pulse output, it shows frequency output value.

Row 2 : fluid density.

Row 3 : PCB temperature.

Row 4 : frequency sensor sampled.

|      |           |
|------|-----------|
| RATE | 10.5 m3/h |
| TOT. | 20.0 m3   |
| TEMP | 25°C      |
| PRES | 1.5MPa    |



|      |           |
|------|-----------|
| OUT  | 12.5mA    |
| DEN  | ----kg/m3 |
| E.T. | 23.1°C    |
| IN   | 88hz      |

Display without Temp./ Pressure compensation

If choose the application of "1. Gas" or "2. Liquid ", only 2 lines will display, That is flowrate and totalizer.


Row 1 : output content. If choose current output, it shows the output current value; If choose pulse output, it shows frequency output value.

Row 2 : fluid density.


Row 3 : PCB temperature.


Row 4 : frequency sensor sampled.

**8. General Parameter Operation chart**




### 9. Calibration Parameter Operation Chart






## 10. General Parameter Setting

### 10.1 Parameter and Adjustment information setting





FLUID DENSITY  
0740.000 kg/m3

Density Setting  
Setting Range : 0.000000~99999999 kg/m3  
Fluid density setting only for Engineering Unit are Kg/H or T/H



GAS PRESSURE  
0.101325 Mpa

ATM Pressure  
Setting Range : 0.000000-99999999 Mpa  
Local Pressure original setting value : 0.101325 Mpa



STD. TEMP.  
00 °C

Standard Temperature  
Setting Range : 00-99 °C  
Local pressure original setting value : 00



FLOW CUTOFF  
00.000 m3/h

Low Flowrate Cut Off  
Setting Range : 0.000000-99999999  
When it's lower than the setting value, it won't display, Normally setting the Max. flowrate is 5%



COMMUNICATION  
NO

Communication mode  
1. No 2. RS-485 3. RS-232



ADDRESS  
0000

Communication Address  
Setting Range : 0000-9999



SENSOR TYPE  
STANDRAD

Sensor Type  
1. Standard Type 2. Special 3. Insert Type



SAVE  
YES NO

Parameter Save  
Select whether to save the parameter setting, and turn back to main function  
**Press SET for 3 second, then loose, and turn back to main function**



PARAMETER B  
MODIFY A  
TOTALIZER C  
PASSWORD K

### 10.2 Tantalization Zero Clearing

|                  |          |
|------------------|----------|
| PARAMETER        | B        |
| MODIFY           | A        |
| <b>TOTALIZER</b> | <b>C</b> |
| PASSWORD         | K        |

Parameter and adjust information setting main function  
 Press **▶** button could select: parameter setting, Modify, totalization reset, password revised.  
 Select TOTALIZER and press **SET** button to do the operation.

↓ **SET**

|          |
|----------|
| PASSWORD |
| 1234     |

Input Password : **1234** and it will go to totalization zero clearing operation

↓ **SET**

|             |
|-------------|
| CLEAR TOTAL |
| YES NO      |

Totalization Zero Clearing  
 Select if it needs Totalization Zero Clearing

### 10.3 Password Revised

|                 |          |
|-----------------|----------|
| PARAMETER       | B        |
| MODIFY          | A        |
| TOTALIZER       | C        |
| <b>PASSWORD</b> | <b>K</b> |

Parameter and adjust information setting main function  
 Press **▶** button could select: parameter setting, Modify, totalization reset, password revised.  
 Select PASSWORD and press **SET** button to do the operation.

↓ **SET**

|              |
|--------------|
| NEW PASSWORD |
| 0000         |

Password Revised  
 Revised to new password

↓ **SET**

|        |
|--------|
| SAVE   |
| YES NO |

Save Parameter  
 Select if it needs Save Parameter Setting, and go back to Main Function



# 11. Calibration Parameter Setting



## 11.1 Temp. Calibrate Operation

RATE 10.5 m3/h  
TOT. 20.0 m3

RATE 10.5 m3/h  
TOT. 20.0 m3  
TEMP 25°C  
PRES 1.5MPa



CAL

TEMPERATURE B  
PRESSURE A  
mA OUTPUT C  
ZERO POINT K

**Calibration Setting Main Function**  
Press  button could select: Temp. Calibration, Pressure Calibration, Electric Current Calibration, Zero Point Calibration  
Select TEMPERATURE and press  button to do the operation.


CAL

PASSWORD  
1234

**Input Password : 1234** and go to Temp. Calibrate operation  
Press  button to move the position, press  button to change the digit.



CAL

TEMP CALIBRATION  
SET RES. BACK

**Temp. Calibration Function**  
Window Selection : Setting / AUTO / Turn Back  
Press  button to move the position

CAL

TEMP SET HIGH  
3023.1

**Setting Temp. Calibration Mode**  
Input Temp. Up Limit  
Press  button to move the position, press  button to change the digit.

CAL

TEMP SET LOW  
0750.2

**Setting Temp. Calibration Mode**  
Input Temp. Lower Limit  
Press  button to move the position, press  button to change the digit.

CAL

SAVE  
YES NO

**Save Setting**  
Select if it needs Save Setting  
Press  button to confirm

### 11.2 Pressure Calibrate Operation

|                 |          |
|-----------------|----------|
| TEMPERATURE     | B        |
| <b>PRESSURE</b> | <b>A</b> |
| mA OUTPUT       | C        |
| ZERO POINT      | K        |

CAL

**Calibration Setting Function**  
 Press **▶** button could select: Temp. Calibration, Pressure Calibration, Electric Current Calibration, Zero Point Calibration.  
 Select PRESSURE and then press **CAL** button to do the operation.

PASSWORD  
**1234**

CAL

**Input password : 1234** and it will go to pressure calibrate operation  
 Press **▶** button to move the position, press **▲** button to change the digit.

PRE. CALIBRATION  
 SET CAL. BACK

CAL

**Pressure Calibration Mode**  
 Window selection: Setting / Calibration / Turn back  
 Press **▶** button to move the position

PRE. SET HIGH  
 2972.6

CAL

**Setting Pressure Calibration Up Limit**  
 Input Pressure High Limit  
 Press **▶** button to move the position, press **▲** button to change the digit.

PRE. SET LOW  
 0967.4

CAL

**Setting Pressure Calibration Lower Limit**  
 Input Pressure Low Limit  
 Press **▶** button to move the position, press **▲** button to change the digit.

SAVE  
 YES NO

CAL

**Save Setting**  
 Select if it needs Save Setting  
 Press **CAL** button to confirm

### 11.3 Electric current output calibration

|                  |          |
|------------------|----------|
| TEMPERATURE      | B        |
| PRESSURE         | A        |
| <b>mA OUTPUT</b> | <b>C</b> |
| ZERO POINT       | K        |

CAL

|             |
|-------------|
| PASSWORD    |
| <b>1234</b> |

CAL

|                    |
|--------------------|
| mA                 |
| <b>CALIBRATION</b> |
| SET CAL. BACK      |

CAL

|        |     |      |
|--------|-----|------|
| mA     | SET | 20mA |
| 004235 |     |      |

CAL

|        |     |     |
|--------|-----|-----|
| mA     | SET | 4mA |
| 000711 |     |     |

CAL

|        |
|--------|
| SAVE   |
| YES NO |

**Calibration Setting Function**  
 Press **▶** button could select: Temp. Calibration, Pressure Calibration, Electric current calibration, Zero point calibration.  
 Select mA OUTPUT and press **CAL** button to do the operation.

**Input Password : 1234** and it will go to the electric current calibrate operation  
 Press **▶** button to move the position, press **▲** button to change the digit.

**Electric Current Calibration**  
 Window Selection : Setting, AUTO, Turn back  
 Press **▶** button to move the position,

**Adjust 20mA Output**  
 20 mA electric current output value amended, if mA output value too low, please increase the value, if the value too high, please decrease the value.  
 Press **▶** button to move the position, press **▲** button to change the digit.

**Adjust 4mA Output**  
 4 mA electric current output value amended, if mA output value too low, please increase the value, if the value too high, please decrease the value.  
 Press **▶** button to move the position, press **▲** button to change the digit.

**Save Setting**  
 Select if it needs Save Setting  
 Press **CAL** button to confirm

### 11.4 Zero Point Calibration Operate

TEMPERATURE B  
 PRESSURE A  
 mA OUTPUT C  
**ZERO POINT K**

**Calibration Setting Main Function**  
 Press **[>]** button could select: Temp. Calibration, Pressure Calibration, Electric current calibration, Zero point calibration.  
 Press ZERO POINT and then press **[CAL]** button to do the operation.

**PASSWORD**  
 1234

Input password: **1234** and it will go to the Zero calibrate operation  
 Press **[>]** button to move the position, press **[▲]** button to change the digit.

**ZERO CALIBRATION**  
 MENU AUTO BACK

**Zero Point Calibration**  
 Window Selection: By manual / Auto / Turn back. Press **[>]** button could select.  
**If choose the MENU, will come to next window. Then set zero manually.**

**SET ZERO VALUE**  
 4

**Zero Point Calibration by manual**  
 Zero Point Adjust Range: :0 - 7  
 Press **[▲]** button to change the digit.

**SAVE**  
 YES NO

**Save Setting**  
 Select if it needs Save Setting  
 Press **[CAL]** button to confirm

● **Zero Adjustment**

When sensor installed in the pipe, the pipe with no flowrate, and shows the low flow rate in display, then please does the Zero Adjustment.

**Situation 1:** Zero Adjustment could through the shortcut key of electrical board as follow.

Press the **[ZERO]** button about 5 seconds, the light is turned on, then loosen the button, when light about 5 seconds, it start glitter, and will enter into zero adjustment status, the glittering time about 3 seconds, the zero adjustment is completed once the light turn off.

**Situation 2:** Through the window to do the zero adjustment. It will search the zero position. Please check 11.4 Zero Point Calibration Operate. When you finished the auto zero adjustment, the small flowrate still exist, please press CAL button at Zero Point Calibration selected MENU (hand zero adjustment), if the value is 3, please add the zero point value. Change to 4, whether the status improved, if it still exists, please adds one more point. The bigger the value is, the better the anti-interference. But when the value too big, it will cause no signal, please select carefully.

